

spec⁵

SpecFive Linx

User Guide



Thank you for ordering your SpecFive Linx from SpecFive.

What's in the Box

- 1x Spec5 Linx PoC Radio
- Pre-installed 4G SIM Card (2GB Data + 1 Year Service)
- USB-C Charging Cable
- This Quick Start Guide

Power & Charging

Power On / Volume:

Turn the top volume knob clockwise to power on and increase volume. Counterclockwise to turn off or reduce volume.

Charging & Wired Audio:

The USB-C port on the right side is used for charging and compatible wired headsets.

Battery Life:

~6 hours use / 24 hours standby

Charge Time:

~3 hours

Push-to-Talk (PTT)

Press and hold the PTT button on the left side of the Linx to speak. Release to listen.

Navigation Controls (Non-Touchscreen)

Button	Function
Green Call Button	Select / Confirm
Red Call Button	Back / Cancel
▲ / ▼	Navigate Up / Down
P1	Left Arrow
P2	Right Arrow

Connectivity

- Device comes preloaded with an active 4G SIM – ready to use
- Optional: Connect to WiFi
 - Navigate to Settings > WiFi, select your network, and enter the password

Zello Account Setup (Required)

On Your Phone:

1. Download Zello from the App Store or Google Play
2. Tap Sign Up and create a username, email, and password

On Your Computer:

1. Visit <https://zello.com>
2. Click Sign Up and fill out the form

Log In on the Linx

1. Power on the device
2. Open the Zello app
3. Use the navigation buttons to enter your Zello username and password
4. Press the Green Call Button to log in

Using Zello on the Linx

- Use the PTT button to talk
- Navigate contacts and team channels with ▲ ▼ P1 P2
- Compatible with Bluetooth PTT headsets (sold separately)
- Works seamlessly with other Zello users on phones, tablets, and computers

Features Summary

- Push-to-Talk over 4G / WiFi
- USB-C Port (Right Side) – Charging & Wired Audio
- PTT Button (Left Side)
- Android 5.1.1 OS
- GPS Location Services
- Bluetooth Connectivity

Support

Visit: <https://specfive.com/support>

Email: support@specfive.com